

Optimal sensor placement



Place and secure the sensor so there is no tension on the black fiber, and in a direction so the soft line can be retained when moving/bending the arm.



If the black fiber is kinked the light path will be interrupted and a warning or alarm may be triggered. The sensor fiber is flexible and will remain intact but the treatment will have to be started over.